
DART SERVICE INSTRUCTION


REFERENCE IIN-D209-669 REV. A OR LATER APPROVED REVISION

The D209-669-041 Skidtube Kits at CHG 000 are identical to D209-669-041 Skidtube Kits at CHG 001 except that the CHG 000 skidtubes are equipped with a Bell P/N 209-050-123-1 Fitting in the front end of the skidtube instead of the Dart D2855 Cap. This fitting is to be used for ground handling maneuvers. The Dart D2968-041 Tow Ring is not required for CHG 000 skidtubes.

At the customer's option, the D2968-041 Tow Rings can be installed on the D209-669-041 Skidtube Kits at CHG 000 by drilling a Ø0.640 hole through the skidtube as shown below and installing the tow rings per IIN-D209-669 Rev. A. Deburr and touch up the holes with MIL-P-85582 or MIL-P-23377 primer before installation of the tow rings.



<u>D209-669-041 Skidtube Kit at CHG 000</u> (Part of D209-669-011/-012 at CHG 000)



<u>D209-669-041 Skidtube Kit at CHG 001</u> (Part of D209-669-011/-012 at CHG 001)

Α	NEW ISSUE CE			СВ	07.08.10
REV.		DESCRIPTION			DATE
DESIGN C.		CB	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA		
DRAWN		CB			
CHECKED		PH.	DRAWING NO.		REV. A
MFG. APPR.		91	DSI 9371	;	SHEET 1 OF 1
APPROVED		-11	TITLE		SCALE
DE APPI	DE APPR.		D209-669-041 AT CHG 000 N		NTS
DATE 07.08.10			COPYRIGHT © 2007 BY DART AEROSPACE LTD THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.		